
USB
GROUND 10 GND
+3.3V 1 3V3
MOIS 7 GP19
SCK 2 GP18
Panel / CS 9 GP17
MISO 6 GP16
GP10 8 Flash / CS
GP11 5 /RESET
GP12 4 D/C
GP13 3 BUSY
PERVASIVEDISPLAYS
Connect to EXT3 board with the 10-way cable.
© PDi 2021